



## MC 360 | Optional Remote Access


# Remote Access to your Stalker Message Center 360


Driving all the way out to your roadside MC360 unit(s) takes up valuable time and resources. The Shield Communications Plan, available on all MC360 variable message signs, gives users the ability to access their sign(s) remotely via mobile device, laptop, or desktop. Change your sign's message, update the schedule, or even download all your radar-collected data with just a few clicks.



### Powerful Remote Features

- Change message or graphics on one board or a group of boards simultaneously
- View minute-by-minute battery voltage reports
- Set schedules and alerts
- Dual radar modes
  - Speed Enforcement Mode
  - Data Collection Mode
- Retrieve and download traffic data
- Store messages and graphics in a common library
- Set Geofencing







Simple user-friendly interface



Minute by minute battery voltage reports




Built in traffic data reporting



Quick and easy GeoFencing

## Intuitive Interface

In this modern age, the days of requiring an operator to drive from message board to message board to update, download data, or check battery voltage are over. Now, with a connected Stalker Message Center 360, the locations of all connected message center boards are displayed on an intuitive map interface.



## Remote Updates of Messaging and Graphics

Through the use of floating pallets, message and graphic updates can be quickly executed. All functions of the message board are accessed with a few clicks of a mouse. Font size, display timing, and radar operations can be updated and scheduled on demand. Often used messages and graphics can be saved to a common library for efficient recall. Minute-by-minute battery voltage reports help to monitor key message board systems.

## Switch Radar Modes

### Speed Enforcement Mode

Also called Police Mode, a full range of speed detection functions are available. Minimum speed messaging, maximum speed messaging, and violator speed messaging are controlled by the intuitive interface.

## Data Collection Mode

Also called Legacy Mode, a trip speed is set with the corresponding messaging and scheduling functions.

## Download Traffic Data

Remote download of your traffic data is an important function of the interface. Management of data can be done directly through the interface, or imported into the Stalker Easy Analyst software for interpretation and reporting.

## Set GeoFence

A GeoFence, or virtual boundary, sets triggers for an email or text message alert once the unit leaves the boundary. This is a useful tool for security and custom travel time functions.

**STALKER**  
**STREET DYNAMICS**

applied concepts, inc.

855 East Collins Blvd. ■ Richardson, Texas 75081  
972.398.3780 ■ Fax 972.398.3781



**1-800-782-5537**  
**StreetDynamics.com**

006-0612-00 Rev C